


NOTE: Follow **EXACTLY** the sequence . STEP 1 -> STEP 2

STEP 1) file needed : **SolarEnergyECUMulti-X.Y.Z** (Thi is the main FW Image)

Upgrade this always as first .

Go to "Upgrade" and select the file "SolarEnergyECUMulti-X.Y.Z"

a reboot is automatically issued



STEP 2) file needed : **web-X.Y.X.all** (are all the updated web pages)

Upgrade with this file always AFTER STEP 1

Go to "Settings" -> "FILE MNGR" -> "Upload File" and select the file "web-X.Y.X.all"

No reboot is needed

